

BATTERY WEIGHING SCALE
BW-SERIES
Service Manual

LAST Rev. NO :

LAST Rev. Date : 2009. 06. 18

Table of Contents

1. Proper Operation.....	오류! 책갈피가 정의되어 있지 않습니다.
1.1 Introduction.....	오류! 책갈피가 정의되어 있지 않습니다.
1.2 Model and Specificationl.....	오류! 책갈피가 정의되어 있지 않습니다.
1.3 Environmental Conditions & Safety	오류! 책갈피가 정의되어 있지 않습니다.
2. Classification.....	오류! 책갈피가 정의되어 있지 않습니다.
3. Getting Started.....	오류! 책갈피가 정의되어 있지 않습니다.
4. Calibration Mode	오류! 책갈피가 정의되어 있지 않습니다.
4.1 Calibration.....	오류! 책갈피가 정의되어 있지 않습니다.
4.2 Self Test.....	오류! 책갈피가 정의되어 있지 않습니다.
5. Servicing & Parts Replacement.....	오류! 책갈피가 정의되어 있지 않습니다.
6. Options Installing	오류! 책갈피가 정의되어 있지 않습니다.
7. Update	오류! 책갈피가 정의되어 있지 않습니다.
8.1 F/W update	오류! 책갈피가 정의되어 있지 않습니다.
8. Exploded Views	오류! 책갈피가 정의되어 있지 않습니다.
9. Revision	오류! 책갈피가 정의되어 있지 않습니다.

1. Proper Operation

1.1 Introduction

The service manual is the specification for the BW-SERIES. They have been designed with CAS reliability under rigid quality control and with outstanding performance.

This manual includes basic technical about composition of hardware and program function.

1.2 Model and Specification

Model Item		BW-1N				
		BW-6	BW-15	BW-30	BW-60	BW-150
Max Capacity		6kg	15kg	30kg	60kg	150kg
Interval		2g	5g	10g	20g	50g
Platter Size		280(W) x 280(D) x 80(H)			405(W) x 525(D) x 105(H)	
Product Size		280(W) x 350(D) x 530(H)			425(W) x 675(D) x 755(H)	
Product Weigh		About 6 kg			About 17 kg	
Charge Time		About 6 hr				
Discharge		About 30 hr (BL ON), About 60 hr (BL OFF).				
Function	General	ON/OFF, Zero, Net, Hold, PCS, RS232, HI, LO, Compare				
	Option	Backlight				
Operatint Temp		-10℃ ~ +40℃				
Tare		Max Capacity				
Display		6 Digit LCD(24mm Height) Stable(), Zero (), Tare (), Net (), Hold (), Low battery (), Weight unit (kg), High, OK, Low (), Count()				
Power (Option)		1. DC 7.2V(6EA SIZE " AA ") 2500mAh Rechargeable battery 2. DC 9V(6EA SIZE " C ") Dry Battery 3. DC 12V 1.25A AC Adaptor				
Power consumption		approx. 0.25W				

1.3 Environmental Conditions & Safety

- Do not press the key strongly
- Do not install in the place with sudden temperature change.
- Do not install in the place with excessive electrical noise and shaking.
- Do not use the inflammable at cleaning.
- Do not use in the place exposed directly to the sun and including much dust.
- Charge a battery in full to use after negligence for a long time.
- Install the platform on a flat place.
- Do not install in the place with voltage and terrible electrical noises.
- Never connect AC adaptor while using the dry battery.

1.4 Installation

CAS




FIG. 1

FIG. 2

FIG. 3

How to install the BW-series


1. Open the box with care because indicator is connected to the scale with load cell wire.
2. Turn the post knob so as to fix indicator.
3. Pull down the wire out of post pipe and insert the post pipe to the post bracket. (Refer to fig. 1)
4. Fasten the post pipe with two bolts. (Refer to fig. 1)
5. A long bolt should be connected to the upper side.
6. Insert the wire to the post pipe. (Refer to fig. 2.3)
6. If the scale is not properly level, please adjust 4 leg (adjusting bolt) at the bottom of the scale so as to center the bubble of the leveling gauge.

Note: Place the scale on a flat and stable surface.
inside the indicated circle.


2. Classification

BW-6, BW-15, BW-30, BW-60, BW-150 모델별 제품 사진 추가 필요

2.2 Part Name



2.2 Display



LAMP	SYMBOL	DESCRIPTION
STABLE		ON when current weight is stable
ZERO		ON when current weight is 0
NET		ON at displaying the pure weight
HOLD		ON at weighing the moving object
TARE		ON when tare is activated.
HI		ON when current weight is more than high limit value.
OK		ON when current weight is right weight band.
LOW		ON when current weight is less than low limit value.
BAT		Display the battery recharging time (rechargeable battery) Display the battery replacing time (dry battery) - about 6.9V remain
PCS		ON when current mode is count mode.
CHARGE		When charging battery, charging lamp (RED) is ON. When it is completed, charging lamp (GREEN) is ON.
POWER		ON at connecting the DC 12V adapter.
Minus		ON when weight is “-“
Kg		Weight unit

3. Getting Started

Moving method

Open the top cover of indicator and power on with pressing CAL switch in the left top. At that time, LCD screen shows “ZEro=tEst tArE=CA” message and pressing ‘Zero’ key moves to Test 1.

Test menu (tEst 1 ~ tEst 4)

TEST 1: Liquid crystal display test

TEST 2: A/D conversion test

TEST 3: Key test

TEST 4: RS-232C communication test

TEST 1 (Enter 'TEST' mode to start TEST 1.)

FUNCTION : Liquid crystal display Test		
KEY	LC DISPLAY	DESCRIPTION
ENTER Key : Next menu		Display TEST 1 state.

TEST 2

FUNCTION : A/D conversion test		
KEY	LC DISPLAY	DESCRIPTION
ENTER Key : Next menu		Display TEST 2 state.
ZERO Key : Use to set the current value to "0"		Display the digital value corresponding to current weight.

- Note 1. Check whether the digital value is changing whenever you load or unload the weight on the platter. If the digital value is fixed or zero is displayed, please check the connection of loadcell.

TEST 3

FUNCTION : Key test		
KEY	LC DISPLAY	DESCRIPTION
ENTER key : Next menu		Display TEST 3 state.
Other key : Test execution		Press the key to be tested and the No. of key mode should be identifying with code of key as the follows.

<KEY CODE>

KEY	CODE	KEY	CODE
*	1	GROSS /NET	4
ZERO	2	HOLD or kg/lb	5
TARE	3		

TEST 4

FUNCTION : RS-232C communication test		
KEY	LC DISPLAY	DESCRIPTION
ENTER key : Move to weighing mode. Other key : Execute data transmission to a computer.		Display TEST 4 state.
		Waiting for transmission and reception.
		Received : None, Transmitted : 1
		Received : 2, Transmitted : 1
		Press ENTER key.
		When this test is completed, it is automatically moved to NORMAL MODE.

- ▶ Note 1. Connect the computer COM port with RS232C connector of indicator before running this test.
- ▶ Note 2. Send No. 2 in computer keyboard and check if indicator receives No.2 send No. 1 in indicator keyboard and check if computer receives No.1


Sealing methode

Perform the sealing as shown in the below figure after the calibration is completed.

Open the top cover.

Cover CAL switch in the left top of cover with sealing plate and screw 2 sealing bolt.

Connect the sealing wire as follows and compress the sealing lead.



4. Calibration Mode

Moving method

Open the top cover of indicator and power on with pressing CAL switch in the left top. At that time, LCD screen shows “ZEro=tESt tArE=CaL” message and pressing ‘TARE’ key moves to CAL 1.

Calibration menu (CAL 1 ~ CAL 5)

CAL 1 : Maximum Capacity Set

CAL 2 : Minimum Division Set

CAL 3 : Setting Weight in Span Calibration

CAL 4 : Zero Calibration

CAL 5 : Span Calibration

Digit input method

NET/GROSS Key : Increase the first place value by 1.

TARE Key : Move to the left by 1 place.

ZERO/MODE Key : Set the inputted value to “0”.

ENTER Key : Move to the next menu.

CAL 1

FUNCTION : Maximum Capacity Set (Range : 1 ~ 99,999)		
KEY	LC DISPLAY	DESCRIPTION
Input by digit input method.		CAL 1 condition
ENTER : save and go to next menu		200 Kg

CAL 2

FUNCTION : Minimum Division Set (Range : 0.001 ~ 50)		
KEY	LC DISPLAY	DESCRIPTION
NET/GROSS key:		CAL 2 condition
Input the next division		0.5 Kg
TARE key:		

Service Manual – BW Series REV NO :

Input the previous division		
ENTER key: Move to the next menu		

- ▶ Note 1. The minimum division means the value of one division.
- ▶ Note 2. External resolution is obtained by dividing the min. division by the maximum capacity. Set the resolution to be within 1/10,000.
- ▶ Note 3. The maximum capacity/minimum division is over 10,000, error message “CH 11” will occur.

CAL 3

FUNCTION : Setting Weight In Span Calibration		
KEY	LC DISPLAY	DESCRIPTION
Input by digit input method.		CAL 3 condition
ENTER : save and go to next menu		200 Kg

- ▶ Note 1. The span weight shall be within 10-100% of maximum capacity.
The initial span weight is 100% of max. capacity but if the current span weight is different from it, input the desired weight again.
- ▶ Note 2. The span weight shall be above 10% of maximum capacity.
If not so, an error message “ERR22” is shown.
- ▶ Note 3. Never install the span weight higher than maximum capacity because an error message “ERR23” is shown.

CAL 4

FUNCTION : Zero Calibration		
KEY	LC DISPLAY	DESCRIPTION
ENTER key : Move to next menu after zero calibration	 	Empty the platform and when LCD screen shows “ULOAD”, press ‘ENTER’ key. After completing zero calibration, it will be automatically moved to CAL 5.

- ▶ Note 1. Zero calibration is performed automatically by program.
Loadcell output is automatically adjusted within 0.05mV and 5mV.

CAL 5

FUNCTION : Span Calibration		
KEY	LC DISPLAY	DESCRIPTION

ENTER key : Span calibration	CAL 5 LoAd End Err24	Put the weight set in CAL3 on platform and press 'ENTER' key. Span calibration is terminated. Error occurrence. Move into initial menu automatically.
------------------------------	--	---

► Note 1. Display "END" message and move into the NORMAL MODE at completion of span calibration

► Note 2. At occurrence of ERR24, reset by lowering the resolution.

5 Conversion Mode

1. ENTER method

If you press the * key for three seconds to normal operation state, after display "SET" Message for one second and then enter.

2. KEY using



Move to the next menu.



Increase the set point.



Return to the normal operation at completion of setting :[ENTER] key.

3. CONVERSION menu (F01 - F06)

- F - 1 : Auto power OFF setting.
- F - 2 : RS-232C communication setting.
- F - 3 : Select print format type.
- F - 4 : Stable condition
- F - 5 : Display Time Control
- F - 6 : Hold Time Control

■ F – 1 : Auto power OFF setting

Auto power OFF function is used to spare the battery by means of power off when this scale is not used.

Set point	Meaning
F – 1 0	Auto power OFF is not used
F – 1 1~9	Automatically power off when the weight is not change or no key is used for 1 ~ 9 minutes

Service Manual – BW Series REV NO :

■ F – 2 : RS-232C communication setting

Set point	Meaning
F – 2 0	No transmit
F – 2 1	-
F – 2 2	Transmit at stable weight
F – 2 3	Transmit at data request. (Data request signal "D")
F – 2 4	Use for print mode

■ F - 3 : Select print format type

Set point	Meaning
F – 2 0	Select print format 1
F – 2 1	Select print format 2
F – 2 2	Select print format 1 + Current Time
F – 2 3	Select print format 2 + Current Time

■ F - 4 : Stable Condition

Set point	Meaning
F – 4 1~9	Stable level 1~ 9

■ F - 5 : Display Time Control

Set point	Meaning
F – 5 1~9	Display Time Control (1 : Past, 9 : Slow)

■ F - 6 : Hold Time Control

Set point	Meaning
F – 6 1~7	Hold Time Control (1 : Past, 7 : Slow)

5. Servicing & Parts Replacement



ERROR MESSAGE	REASON	SOLUTION
<i>Err 01</i>	<i>The Indicator can't be initialized due to platform shaking.</i>	<i>Put the platform on a flat place without shaking and power on.</i>
<i>Err 02</i>	<i>The load cell is connected wrongly or A/D conversion part has a fault.</i>	<i>Check that the load cell is well connected with main unit.</i>
<i>Err 03</i>	<i>The calibration isn't executed or the data of internal memory is lost due to a electrical shock.</i>	<i>Perform the required specification again in setting mode.</i>
<i>Err 09 (Zero Key)</i>	<i>The specified TARE weight exceeds the maximum capacity.</i>	<i>Set the TARE weight lower than maximum capacity. Or set the maximum capacity higher than the desired TARE weight in calibration menu and perform the calibration again.</i>
<i>Err 13 (Zero Range with power on)</i>	<i>The initial zero range exceeds above 10% of maximum capacity.</i>	<i>Check the load cell state.</i>
<i>Over</i>	<i>Too heavy object is put on platform so that it may exceed the maximum capacity.</i>	<i>Never put the weight exceeding the maximum capacity. If the load cell is damaged, replace the load cell.</i>
<i>Err 61</i>	<i>The count unit weight and sample weight are set too high.</i>	<i>Set the count unit weight low or the count sample quantity high.</i>
<i>Err 62</i>	<i>The count unit weight and sample weight are set too low.</i>	<i>Set the count unit weight high or the count sample quantity low.</i>

4. L/C 교체 방법 추가 요망

6. Options Installing


Serial Interface (RS-232C)

■ Connecting with PC



Service Manual – BW Series REV NO :

■ Connecting with Sub-display (CD-SERIES)



Print Format

Weight Mode - - - - -

< Format 1 >

No. 001 : 1.00 kg

< Format 2 >

001 : Net 1.00 kg
Tare 0.00 kg
Gross 1.00 kg

< Format 1 + Time >

2005 03. 17 11:23:46
No. 001 : 1.00 kg

※ Printed weight is net weight.

< Format 2 + Time >

2005 03. 17 11:23:46
001 : Net 1.00 kg
Tare 0.00 kg
Gross 1.00 kg

PCS Mode - - - - -

< Format 1 >

No. 001 : 1.00 pcs

< Format 2 >

001 : Net 1.00 pcs
Tare 0.00 pcs
Gross 1.00 pcs

< Format 1 + Time >

2005 03. 17 11:23:46.
No. 001 : 1.00 pcs


※ Printed count is net count.

< Format 2 + Time >


2005 03. 17 11:23:46
001 : Net 1.00 pcs
Tare 0.00 pcs
Gross 1.00 pcs

7. Update


1)




2)




3)




4)




5)



6)



7)




Service Manual – BW Series REV NO :

8. Exploded Views & Parts List


HEAD ASS'Y - COMMON

BW-1 HEAD ASSEMBLY


1




2




3




4



5



6



6-5	SCREW-TAPPING(PH)-2	M3*10	3	
6-4	SPEC PLATE	P#-STICKER TYPE	1	
6-3	SUPPORT PLATE	104*111.2(B)	1	
5	SET ASSEMBLING PART			
5-9	BATTERY RIBBON	NYLON(8m/m*150cm)	1	
5-8	SCREW-TAPPING(PH)-2	M3*6	2	
5-7	BATTERY SPRING C	ø120*21	1	
5-6	BATTERY SPRING B	ø14*21	1	
5-5	BATTERY CONTACT A	ø120*4*ø20	1	
5-4	CONNECTOR WIRE	2P*190cm/m	1	
5-3	BATTERY HOLDER	161*59*30	1	
5-2	BATTERY	C SIZE	6	
4	BATTERY HOLDER ASSEMBLING PART			
4-9	GROUND SPRING	ø16*17*15(BW)	1	
4-8	O-RING	Ø10	2	
4-7	WASHER(FLAT)	ø3*ø6*0.5-SUS	2	
4-6	SCREW-TAPPING(PH)-2	M3*10	4	
4-5	BAR GUIDE BRACKET	72*29.4*7.5*1.5(B)	1	
4-4	RUBBER GUIDE	190*125*10(B)	1	
4-3	CONNECTOR WIRE	5CK-078Y-3P*2.50mm	1	
4-2	CONNECTOR WIRE	5CK-028*3P*170mm	1	
4-1	BODY	205*220*55(ABS)B	1	
3	BODY SUB ASSEMBLING PART			
3-8	STICKER	B/BW, CASTON THA,THD	1	
3-7	BOLT-SEALING	M3*9(including head 3mm)	1	
3-6	SCREW-TAPPING(PH)-2	M3*10	3	
3-5	SCREW-TAPPING(PH)-2	M3*6	5	
3-4	PCB PLATE	180*150*0.8(B)	1	
3-3	DISPLAY PCB ASS'Y	6110-PBW-1040-C	1	
3-2	MAIN PCB ASS'Y	6100-PBW-1040-D	1	
2	PCB ASS'Y & PCB PLATE ASSEMBLING PART			
2-13	SCREW-TAPPING(PH)-2	M3*10	1	
2-12	BOLT-CONNECTOR	M3*13(H)*10(D)	1	
2-11	WASHER(SPR)	ø3	1	
2-10	SUPPORT BAR PLATE	105*105*1.6T	1	
2-9	BAR GUIDE PLATE	19*9*1.2T(B)	1	
2-8	KNOB SPRING	1*13.5*7/4(B)	1	
2-7	SHAFT A	ø2.8*166(B)	1	
2-6	SHAFT B	ø2.8*50(B)	1	
2-5	LEVER GUIDE PLATE	67*21*12T(B)	1	
2-4	DOOR KNOB	40*33*12(B)	1	
2-3	DISPLAY COVER	153.6*60*2T	1	
2-2	KEY BOARD PAD	BLBW-SERIES	1	
2	FRONT COVER SUB ASSEMBLING PART - 2			
1-3	TWIST RIVET	ø2.6*6	2	
1-2	CAPACITY PLATE	BW-SERIES	1	
1-1	FRONT COVER	205*220*32(ABS)B	1	
1	FRONT COVER SUB ASSEMBLING PART - 1			
NO	PARTS NAME	SPECIFICATION	QTY	REMARK
EXPLODED_VIEW				
ANGULAR	IS USED IN	BW-SERIES	MATERIAL	
DECIMAL	IS USED IN		END VIEW	
STYLED	IS USED IN		SCALE	
CONTRACT	IS USED IN		SCALE	
CUSTOMER	IS USED IN		SCALE	
DRAWN	CHECKED	CHECKED	APPROVED	SCALE
-	-	-	-	N/A
-	-	-	-	EXPLODED_VIEW-HEAD
-	-	-	-	EXPLODED_VIEW-HEAD

Service Manual – BW Series REV NO :

SET & C/T BOX ASS'Y – LOW CAPACITY

BW-1(Low) SET & C/T BOX ASSEMBLY

1

2

3

8

EXPLODED VIEW

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

1001

1002

1003

1004

1005

1006

1007

1008

1009

1010

1011

1012

1013

1014

1015

1016

1017

1018

1019


1020

1021

1022

102

BODY ASS'Y – HIGH CAPACITY



Service Manual – BW Series REV NO :

Part List(Electronics Part)

6100-PNT-0300-0	PCB		EA	1	30	
6200-IPU-0845-0	IC(CPU)	ADUC845	EA	1	30	U5
6210-IS0-1274-0	IC(RESET)	TC1274	EA	1	30	U4
6220-IS0-2575-0	IC(REGULATOR)	LM2575-5S(TO-263(S))	EA	1	30	U7
6220-IS0-2576-0	IC(REGULATOR)	LM2576-ADT(TO-263(S))	EA	1	30	U1
6224-I00-7225-0	IC(DRIVER)	UPD7225G00	EA	1	30	U3
6232-IS0-0232-C	IC(INTERFACE)	MAX232ECSE	EA	1	30	U8
6240-IS0-2277-0	IC(OP-AMP)	OPA2277PA-SOP	EA	1	30	U6
6241-IS0-1302-0	IC(CLOCK)	DS1302	EA	1	30	U9
6273-IS0-9020-0	FET	FR9020	EA	1	30	Q2
6280-IS0-0222-0	TRANSISTOR	2N2222(SOP)	EA	3	90	Q5,6,8
6281-I00-1504-0	TRANSISTOR CHIP	KTA1504 SY	EA	5	150	Q1,3,4,7,9
6291-IS0-5819-0	DIODE-POWER	1N5819(SMD)	EA	5	150	CR1-5
6294-ICP-0184-0	DIODE-CHIP	KDS184	EA	2	60	D1,3
6523-MF0-0003-0	RESISTOR-CHIP 1W	(0.3Ω)	EA	1	30	R1
6527-ID0-0470-0	RESISTOR-CHIP 1/10W	RR1220P-470D(47Ω)	EA	2	60	R36,38
6527-ID0-1000-0	RESISTOR-CHIP 1/10W	RR1220P-101D(100Ω)	EA	2	60	R10,11
6527-ID0-4700-0	RESISTOR-CHIP 1/10W	RR1220P-471D(470Ω)	EA	2	60	R33,34
6527-ID3-0010-0	RESISTOR-CHIP 1/10W	RR1220P-102D(1kΩ)	EA	12	360	R2-5,14,19,20,R29,30,32,35,44
6527-ID3-0047-0	RESISTOR-CHIP 1/10W	RR1220P-472D(4.7kΩ)	EA	6	180	R7,24,37,39,41,43
6527-ID3-0100-0	RESISTOR-CHIP 1/10W	RR1220P-103D(10kΩ)	EA	2	60	R18,42
6527-ID3-0200-0	RESISTOR-CHIP 1/10W	RR1220P-203D(20kΩ)	EA	1	30	R40
6527-ID3-1000-0	RESISTOR-CHIP 1/10W	RR1220P-104D(100kΩ)	EA	1	30	R25
6527-ID3-1800-0	RESISTOR-CHIP 1/10W	RR1220P-184D(180kΩ)	EA	1	30	R31
6527-IF3-0010-0	RESISTOR-CHIP 1/10W	FTR 0805 JR(1kΩ)	EA	1	30	R6
6527-IF3-0069-0	RESISTOR-CHIP 1/10W	FTR 0805 JR(6.98kΩ)	EA	1	30	R12
6527-IF3-0100-0	RESISTOR-CHIP 1/10W	FTR 0805 JR(10kΩ)	EA	4	120	R8,9,16,17
6527-IF3-0470-0	RESISTOR-CHIP 1/10W	FTR 0805 JR(47kΩ)	EA	1	30	R15
6527-IF3-1000-0	RESISTOR-CHIP 1/10W	FTR 0805-470kΩ	EA	1	30	R21
6527-IJ0-0020-0	RESISTOR-CHIP 1/10W	FTR 0805 JR(2Ω)	EA	3	90	R13,26,28
6540-LA3-0010-0	RESISTOR-PRECISION	FLAY1K000B	EA	1	30	R27
6540-LA3-0280-0	RESISTOR-PRECISION	FLAY28K000B	EA	2	60	R22,23

Service Manual — BW Series REV NO :						
6550-M09-0223-0	RESISTOR-NETWORK	MG-1=2233(BW)	EA	1	60	RA1
6670-T00-0220-0	INDUCTANCE	220UH	EA	2	60	L11,8
6670-T01-0010-0	INDUCTANCE	10uH(장구)	EA	2	60	L2,4
6670-T01-0010-0	INDUCTANCE	220UH(장구)	EA	2	60	L9,10
6670-T02-0047-0	INDUCTANCE	47uH	EA	5	150	L1,3,5~7
6704-C25-0100-0	CONDENSER-ELECTRIC	100UF/25V	EA	1	30	C29
6704-C25-0220-0	CONDENSER-ELECTRIC	220UF/25V	EA	3	90	C39,46,55
6704-C25-3300-0	CONDENSER-ELECTRIC	3300UF/25V	EA	1	30	C31
6710-CAP-P102-B	CONDENSER-CERAMIC	1000PF/1KV(102K)	EA	1	30	C1
6712-CHP-0102-0	CONDENSER-CHIP	CL21B 102KBNC(1000PF)	EA	15	450	C3-10,12,15,C17,21,22,41,44
6712-CHP-0103-0	CONDENSER-CHIP	CL21F 103KBNC(0.01UF)	EA	2	60	C14,16
6712-CHP-0104-0	CONDENSER-CHIP	CL21F 104KBNC(0.1UF)	EA	27	810	C2,11,13,C18-20,23-27,C30,32-36,40,42,43,45,47-52
6712-CHP-0200-0	CONDENSER-CHIP	CL21C 200JBNC(20PF)	EA	2	60	C53,54
6712-CHP-0300-0	CONDENSER-CHIP	CL21C 300JBNC(30PF)	EA	2	60	C37,38
6804-F00-1046-0	LINE FILTER	L/F1046	EA	1	30	L13
7002-Z00-0120-0	PIEZO BUZZER	14A4012P(EFM-250A)	EA	1	30	BZ1
7010-ZK0-3276-0	CRYSTAL	32.768KHZ	EA	1	30	Y1
7010-ZK0-3276-0	CRYSTAL	32.768KHZ	EA	1	30	Y2
7212-D00-2402-0	LCD	2402TF-P	EA	1	30	LC1
7222-D00-0020-A	E.L BACK LIGHT	DB-11 LCD	EA	1	30	U2
7232-D00-0300-0	LED LAMP	CLL30231(BVL-300E5G)	EA	1	30	LD1
7232-DRG-0003-0	LED LAMP	3φ-(R,G)BL-BVT 201	EA	1	30	LD2
7244-D00-0005-A	E.L INVERTER	MTED-I-5C	EA	1	30	L12
7520-P00-0200-0	BATTERY-LIMN	CR1220-PIN TYPE	EA	1	30	
7600-STA-1104-A	TACT-S/W	KPT-1104B(DJTA-1112A)	EA	6	180	SW2-7
7600-STA-1212-0	TACT-S/W	12*12(SKHK)DJTA-1103	EA	1	30	SW8
7801-CLW-0002-0	CONNECTOR(WAFER)	LW0640-02 (LPH01-02)	EA	2	60	CN3
7801-CLW-0003-0	CONNECTOR(WAFER)	LW0640-03 (LPH01-03)	EA	1	30	CN1
7801-CLW-0005-A	CONNECTOR(WAFER)	LW0640-05(GOLD)	EA	1	30	CN2
7804-CCN-7302-0	CONNECTOR(WAFER)	5273-02 (LPH03-02)	EA	1	30	CN4
	DIP-S/W	EDG-2	EA	1	30	SW1
	CONNECTOR(WAFER)	LW0640-02 (GOLD)	EA	1	30	CN2

기구부 PL 추가필요

Service Manual – BW Series REV NO :

9.Revision

NO	변경 사유(CAUSE)	DATE	변경자 (APPROVAL)	