


NAMES AND FUNCTIONS

OVERALL VIEW

■ HDI




INSTALLATION & CONNECTION

Load cell connection

Connect load cell connector to load cell port which is in the backside of the indicator.

* Connecting method



IN	COLOR
1 (EXC+)	RED
2 (EXC-)	WHITE
3 (SIG+)	GREEN
4 (SIG-)	BLUE
5 (SHIELD)	SHIELD

Красный
серый
Зеленый
Синий

Note. Wire color can be different depending on the Load cell's manufacturer or its model.

* Load cell output to Resolution

5V impression to load cell Max. load cell output	Recommended resolution
---	------------------------